Solar Panel Rewiring Kit



Model: LL-SP-WIRE-D



IMPORTANT

Older Panels are equipped with a diode inside the black junction box on the back of the panel. It is important to REMOVE this old diode as our new wiring kit has a in-line diode that will provide better protection.







Remove the cover Remove the wire clamp

5



Remove old wires, or cut them out if they are soldered



Attach the new fork terminals to the screw terminals



Replace the wire clamp with the hump facing downward



Replace with the new wiring kit, feed fork terminals through hole.



Replace the cover.

