Solar Sky Light + RF Key Fob



Brighter

Dimmer

On/Off

MODEL: LL-SKL-IR-RF

IMPORTANT - WIRELESS OPTION

- ONLY use the On/Off function of the RF Remote Key Fob with your Solar Sky Light 1.
- 2. DO NOT use the dimming function: It will confuse the Motion sensor control.
- 3. In darkness when the Solar Sky Light turns ON, HOLD the UP button to ensure that the Wireless unit is set to FULL brightness.
- 4. Now only use the On/Off Button.
- 5. Do NOT use the dimmer to dim the Light.

OPERATION

- The Wireless Control will ONLY work at Night when the Solar Sky Light is activated. 1.
- 2. At Night, press the ON button, now Hold the UP button for a few seconds to ensure the wireless control is set to full brightness.
- 3. At Night, press the ON button, the Light will automatically turn on each night.
- At Night, press the OFF button, the Light will NOT turn on each night. 4.

DIMMING & STROBE FUNCTIONS – DO NOT USE:

NORMAL (CONSTANT MODE) + DIMMING

- Push On/Off to turn the Light on or off.
- Push UP to make the Light brighter LEAVE UNIT SET IN BRIGHTEST MODE!
- Push DN to make the Light dimmer (DO NOT USE DIMMING)

NOTE (STROBE MODE) DO NOT USE!!

- Pushing UP+DN at the same time will turn the light into a flashing/Strobe Mode.
- Pushing UP will speed up the strobe.
- Pushing DN will slow down the strobe.
- Push ON/OFF to Exit Strobe Mode and return to normal constant lighting mode.
- DO NOT OPERATE the light in strobe mode: push the on/off button to take the wireless unit out of strobe mode.

Owner Registration Card

Please fill out and affix proper postage and return this owner registration card within 10 days to ensure that your new Solar Piling Lite is covered by the limited warranty.

Purchaser's Name

Zip _____

Purchase Date: _____ Number of Lights:

Where Purchased (Store Name):

Address _____

State

Model No	LL-SKL-IR-RF
UPC No.	Varies On Different Models

Lake Lite Inc. 100 Industrial Dr., Avilla, IN 46710

LAKE LITE SOLAR TECHNOLOGY

you must present a copy of the receipt as proof of purchase. All costs of removing and reinstalling

Lake Lite Inc. 1-Year Limited Warranty

the product are your responsibility. Damage to any part such as by accident or misuse or improper installation or by affixing any accessories, is not covered by this warranty. There is no other express warranty. The retailer hereby disclaims any and all warranties, including but not limited to, those of merchantability and fitness for a particular purpose to the extent permitted by law. The duration of any implied warranty, which cannot be disclaimed, is limited to the time period as specified in the express warranty. Some states do no allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you. The retailer shall not be liable for incidental, consequential, or special damages arising out of or in connection with product use or performance except as may otherwise be accorded by law. Some states do not allow the exclusion of incidental or consequential damage, so the above exclusion or limitation may apply to you. This warranty gives specific legal rights, and you may also have other rights, which vary from state to state. This warranty supersedes all prior warranties.

The retailer warrants the Solar Lites to be free from defects in workmanship and material present

original purchaser. We agree to correct such defects without charge or at our option replace with a comparable or superior model if the product is returned to the retailer. To obtain warranty service,

at time of shipment from the factory for a period of one year after the date of purchase by the

Lake Lite Inc. 100 Industrial Dr. Avilla, IN 46710

Phone: 260-918-2758 E-mail: sales@lakelite.com Web: www.lakelite.com

RF Remote

Key Fob

